


BTU Sizing Guide

Model	BF-10T	BF-20T	BF-30T
BTU Input			
Propane Gas	10,000 BTU	20,000 BTU	30,000 BTU
Natural Gas	10,000 BTU	18,000 BTU	30,000 BTU
Gas Inlet Size	3/8"	3/8"	3/8"
BTU Heating Zone			
	----- Heat Coverage Area -----		
(.90 btuh/ft3) Zone 1	676 sq. ft. (26' x 26' room)	1216 sq. ft. (35' x 35' room)	2027 sq. ft. (45' x 45' room)
(1.45 btuh/ft3) Zone 2	568 sq. ft. (24' x 24' room)	1023 sq. ft. (32' x 32' room)	1705 sq. ft. (41' x 41' room)
(1.95 btuh/ft3) Zone 3	481 sq. ft. (24' x 24' room)	865 sq. ft. (29' x 29' room)	1442 sq. ft. (38' x 38' room)
(2.45 btuh/ft3) Zone 4	397 sq. ft. (20' x 20' room)	714 sq. ft. (27' x 27' room)	1190 sq. ft. (35' x 35' room)
(3.15 btuh/ft3) Zone 5	325 sq. ft. (18' x 18' room)	584 sq. ft. (24' x 24' room)	974 sq. ft. (31' x 31' room)



This chart is to be used as a guide only, to assist you in estimating BTU requirements. Actual results may vary depending on your BTU zone and insulating parameters

BTU zones assume spaces meet the average insulation and windows requirements for your zone.

This sizing chart is based on a 72 Degree temperature. To maintain a higher room temperature, please select the next higher BTU zone.

ESN: 85922-070531-776360-56



Copyright © 2008 Alta Power Corp. All Rights Reserved.

